



» DESPIECE



» TABLA DE ESPECIFICACIONES

POSICIÓN	REFACCIÓN	BH35-150-1	BH35-300-2	BH35-500-3	BH35-600-4	BH35-750-5	BH35-1000-6	BH35-1250-7	BH35-1250-8	BH35-1500-10	BH35-1750-11	BH35-2000-12	BH35-2000-13	BH35-2500-14	BH35-2500-15	BH35-2500-16	BH41-250-1	BH41-500-2	BH41-750-3	BH41-1000-4A	BH41-1000-4	BH41-1250-5A	BH41-1250-5	BH41-1500-6	BH41-1750-7	BH41-2000-8	BH41-2500-9	BH41-2500-10	MODELO
1	SUCCIÓN EN 6"	✓	✓	✓	✓												✓	✓											R-BH35/41-SUC6"
	SUCCIÓN EN 8"					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓					✓	✓	✓	✓	✓	✓	✓	✓	R-BH35/41-SUC8"
2	ANILLO DE SELLADO SUCCIÓN	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH35/41-ASS	
	KIT DE ACOPLAMIENTO 6"	✓	✓	✓	✓												✓	✓										R-BH-KITCP6"	
3, 4, 5	KIT DE ACOPLAMIENTO 8"					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓					✓	✓	✓	✓	✓	✓	✓	R-BH-KITCP8"	
	FLECHA EN MTS	✓	✓	✓	✓												✓	✓				✓	✓	✓	✓	✓	✓	R-BH-FLECHA6" R-BH-FLECHA8"	
8	BUJE DE TAZON	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH35/41-BUJE	
9	TAZON	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH35/41-TAZON	
10	O-RING DE TAZON	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH35/41-ORING	
11	IMPULSOR	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓												R-BH35-IMP	
	CONO	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH41-IMP	
12.5	ANILLO DE SELLADO TAZON	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH35/41-ASE	
14	VÁLVULA CHECK	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH35/41-VCH	
16	TAZON DE DESCARGA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH35/41-TD4"	
18	GUARDACABLE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH35/112-GC6"	
		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH35/112-GC8"	


» DESPIECE



» TABLA DE ESPECIFICACIONES

POSICIÓN	REFACCIÓN	BH70-500-1A	BH70-600-1	BH70-1000-2A	BH70-1250-2	BH70-1500-3A	BH70-2000-3	BH70-2500-4	BH86-600-1A	BH86-750-1	BH86-1250-2A	BH86-1500-2	BH86-1750-3A	BH86-2500-3	BH86-2500-4A	BH97-750-1A	BH97-1000-1	BH97-1750-2A	BH97-2500-3A	MODELO	
1	SUCCIÓN EN 8"	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH70/97-SUC8"	
	SUCCIÓN EN 10"							✓						✓	✓				✓	R-BH70/97-SUC10"	
2	ANILLO DE SELLADO SUCCIÓN	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH70/97-ASS
	KIT DE ACOPLAMIENTO 8"	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH-KITCP8"
3, 4, 5	KIT DE ACOPLAMIENTO 10"							✓						✓	✓			✓	✓	✓	R-BH-KITCP10"
	FLECHA EN MTS	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH-FLECHA8"
6								✓						✓	✓				✓	✓	R-BH-FLECHA10"
	BUJE DE TAZON	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH70/97-BUJE
9	TAZON	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH70/96-TAZON
10	O-RING DE TAZON	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH70/96-ORING
11	IMPULSOR	✓	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓	✓						R-BH70-IMP
									✓	✓	✓	✓	✓	✓	✓						R-BH86-IMP
																✓	✓	✓	✓		R-BH97-IMP
12	CONO	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH70/97-CONO
12.5	ANILLO DE SELLADO TAZON	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH70/97-ASE
14	VÁLVULA CHECK	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH70/97-VCH
16	TAZON DE DESCARGA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH70/97-TD4"
18	GUARDACABLE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BH35/112-GC8"
														✓	✓				✓	✓	R-BH35/112-GC10"

» DESPIECE



» TABLA DE ESPECIFICACIONES

POSICIÓN	REFACCIÓN	BH112-1000-1A	BH112-1500-1	BH112-2000-2A	BH112-3000-2	MODELO
1	SUCCIÓN EN 8"	✓	✓	✓		R-BH112-SUC8"
	SUCCIÓN EN 10"				✓	R-BH112-SUC10"
2	ANILLO DE SELLADO SUCCIÓN	✓	✓	✓	✓	R-BH112-ADS
3, 4, 5	KIT DE ACOPLAMIENTO 8"	✓	✓	✓		R-BH-KITCP8"
	KIT DE ACOPLAMIENTO 10"				✓	R-BH-KITCP10"
6	FLECHA EN MTS	✓	✓	✓		R-BH-FLECHA8"
					✓	R-BH-FLECHA10"
8	BUJDE DE TAZON	✓	✓	✓	✓	R-BH112-BUJE
9	TAZON	✓	✓	✓	✓	R-BH112-TAZON
10	O-RING DE TAZON	✓	✓	✓	✓	R-BH112-ORING
11	IMPULSOR	✓	✓	✓	✓	R-BH112-IMP
12	CONO	✓	✓	✓	✓	R-BH112-CONO
12.5	ANILLO DE SELLADO TAZON	✓	✓	✓	✓	R-BH112-ASE
14	VÁLVULA CHECK	✓	✓	✓	✓	R-BH112-VCH
16	TAZON DE DESCARGA	✓	✓	✓	✓	R-BH112-TD4"
18	GUARDACABLE	✓	✓	✓	✓	R-BH35/112-GC8"
					✓	R-BH35/112-GC10"